

# CRS510 Series Instruction



Remove the plastic end caps



Open the top bar and slide the graphic into the top bar



Press down to close the top bar and put the end caps on




Place the hardware upside down and secure the paper with masking tape



Remove the adhesive liner



Attach the graphic onto the paper



Apply packing tape on the graphic and the paper



Remove the masking tape



Remove the chrome end cap and pull out the safety pin



Let the graphic slowly roll into the hardware



Put the chrome end cap on