



Only the left side end cap needs to be opened to pull the locking pin

CRS600 Series Graphic Installation