




INSTRUCTION

CTF Tables



If can't snap when dismantle the frame,Pls push the tube forwardly,then push again.

